


PALLET JACK HANDLE

INSTALLATION INSTRUCTIONS

1. MATCH HANDLE TO FRAME.
2. CUT PLASTIC OFF JUST THE BOTTOM OF THE HANDLE AND REMOVE THE BAG WITH THE HANDLE AXLE



- AND 2 ROLL PINS (1 IS ALREADY INSERTED IN THE AXLE.
3. PUT HANDLE ON TOP OF PUMP WITH CONTROL LEVER ON RIGHT HAND SIDE.
 4. INSERT AXLE, MAKING SURE THAT CHAIN IS IN FRONT OF AXLE. DO NOT SEAT AXLE COMPLETELY.
 5. WHEN AXLE IS THROUGH BOTH SIDES, PUMP THE HANDLE SLOWLY AND REMOVE THE RETAINER WIRE (DISCARD).
 6. FROM FRONT PULL HANDLE DOWN AND DROP CHAIN THROUGH HOLE IN AXLE (TWIST AS NEEDED TO GET CHAIN THROUGH).
 7. SEAT AXLE AND INSTALL ROLL PIN.
 8. FROM FRONT OF TRUCK, LIFT ACTUATOR WITH A SCREWDRIVER AND INSERT END OF CHAIN IN SLOT.
 9. CHECK FOR RAISE, LOWER & NEUTRAL

Customer Minded Associates, Inc.
P.O. Box 1289
Lutz, Fl 33548-1289
Phone 727-360-2323 Fax 727-360-3220
www.customerminded.com
Email: info@customerminded.com